Tt eSPORTS By Thermaltake

ISURUS Pro In-line Remote Operation (Mobile Device)

Player：Spotify

Version：2.2.0.2464

OS	Brand	Android Ver.	Button / Mobile Phone mode	Play/Pause Button	Previous Button	Next Button
Android	Xiaomi	4.0.4	Xiaomi 1S	Press once to Start or Stop audio	Press once for Previous track	Press once for Next track
		4.1.1	Xiaomi 2	Press once to Start or Stop audio	Press once for Previous track	Press once for Next track
		4.1.1	Xiaomi 2S	Press once to Start or Stop audio	Press once for Previous track	Press once for Next track
		4.4.2	Xiaomi 3	Press once to Start or Stop audio	Press once for Previous track	Press once for Next track
		4.2.1	Hongmi	Press once to Start or Stop audio	Press once for Previous track	Press once for Next track
		4.1.1	Xiaomi 2	Press once to Start or Stop audio	Press once to Increase volume	Press once to Decrease volume
					Press three times for Previous track	Press twice for Next track
		4.1.1	Xiaomi 2S	Press once to Start or Stop audio	Press once to Increase volume	Press once to Decrease volume
				Press once to Start or Stop audio	Press three times for Previous track	Press twice for Next track
		4.4.2	Xiaomi 3	Press once to Start or Stop audio	Press once to Increase volume	Press once to Decrease volume
				Press once to Start or Stop audio	Press three times for Previous track	Press twice for Next track
		4.2.1	Hongmi	Press once to Start or Stop audio	Press once to Increase volume	Press once to Decrease volume
				Press once to Start or Stop audio	Press three times for Previous track	Press twice for Next track
	Xiaomi	Note: Xiaomi's smart phone series can setup functions for previous, next, play & pause button or Increase/Decrease volume. User can manage the button functions accordingly by your own requirement. Please refer to your smart phone's user manual for further details.				
	Samsung	5.0.2	Samsung Galaxy S6 Edge	Press once to Start or Stop audio	Press once to Increase volume	Press once to Decrease volume
		5	Samsung Note 3	Press once to Start or Stop audio	Press once to Increase volume	Press once to Decrease volume
		4.1.1	Samsung GT-S7572	Press once to Start or Stop audio	Press once to Increase volume	Press once to Decrease volume
				Press once to Start or Stop audio	Press three times for Previous track	Press twice for Next track
		4.1.1	Samsung GT-N7100	Press once to Start or Stop audio	Press once to Increase volume	Press once to Decrease volume
				Press once to Start or Stop audio	Press three times for Previous track	Press twice for Next track
		4.1.1	Samsung GT-I9268	Press once to Start or Stop audio	Press once to Increase volume	Press once to Decrease volume
				Press once to Start or Stop audio	Press three times for Previous track	Press twice for Next track
		4.3	Samsung N7506 4G	Press once to Start or Stop audio	Press once to Increase volume	Press once to Decrease volume
				Press once to Start or Stop audio	Press three times for Previous track	Press twice for Next track
		4.3	Samsung S3 i9300	Press once to Start or Stop audio	Press once to Increase volume	Press once to Decrease volume
				Press once to Start or Stop audio	Press three times for Previous track	Press twice for Next track
	Samsung	Note: SAMSUNG Mobile Devices with Android 5.0 above will not be able to use the Next & Previous feature function				
	HUAWEI	4.2.2	HUAWEI H30-U10	Press once to Start or Stop audio	Press once for Previous track	Press once for Next track
		4.2.2	HUAWEI G700-U00	Press once to Start or Stop audio	Press once for Previous track	Press once for Next track
		4.2.2	HUAWEI Y511-T00	Press once to Start or Stop audio	Press once for Previous track	Press once for Next track
		4.2.2	HUAWEI U9508	Press once to Start or Stop audio	Press three times for Previous track	Press twice for Next track
		4.4.2	HUAWEI H60-L01	Press once to Start or Stop audio	Press once to Increase volume	Press once to Decrease volume
				Press once to Start or Stop audio	Press three times for Previous track	Press twice for Next track
		4.2	HUAWEI Mate 2 4G	Press once to Start or Stop audio	Press once to Increase volume	Press once to Decrease volume
				Press once to Start or Stop audio	Press three times for Previous track	Press twice for Next track
	HTC	4.0.3	HTC G21	Press once to Start or Stop audio	Press once for Previous track	Press once for Next track
		4.0.3	HTC X315e	Press once to Start or Stop audio	Press once for Previous track	Press once for Next track
		4.4.2	HTC 820mu	Press once to Start or Stop audio	Press once for Previous track	Press once for Next track
		4.4.2	HTC D820u	Press once to Start or Stop audio	Press once for Previous track	Press once for Next track
		4.4.2	HTC M8Sw	Press once to Start or Stop audio	Press once for Previous track	Press once for Next track
		4.4.4	HTC M8w	Press once to Start or Stop audio	Press once for Previous track	Press once for Next track
	Vivo	4.2.1	Vivo X3t	Press once to Start or Stop audio	Press three times for Previous track	Press twice for Next track
	Lenovo	4.4.2	Lenovo A820T	Press once to Start or Stop audio	Press once for Previous track	Press once for Next track
		4.4.2	Lenovo A680	Press once to Start or Stop audio	Press once for Previous track	Press once for Next track
		4.4.2	Lenovo S850t	Press once to Start or Stop audio	Press three times for Previous track	Press twice for Next track
		4.4.2	Lenovo X2-TO	Press once to Start or Stop audio	Press three times for Previous track	Press twice for Next track
		4.4.2	Lenovo S858t	Press once to Start or Stop audio	Press once for Previous track	Press once for Next track
	LG	5.0	LG G2	Press once to Start or Stop audio	Press once to Increase volume	Press once to Decrease volume
					Press three times for Previous track	Press twice for Next track
		5.0	LG G3	Press once to Start or Stop audio	Press once to Increase volume	Press once to Decrease volume
					Press three times for Previous track	Press twice for Next track
	SONY	4.4	SONY M50W	Press once to Start or Stop audio	Press once to Increase volume	Press once to Decrease volume
		4.4	SONY L55t	Press once to Start or Stop audio	Press once to Increase volume	Press once to Decrease volume
		5.0.2	SONY Z3	Press once to Start or Stop audio	Press once to Increase volume	Press once to Decrease volume

OS	Brand	iOS Ver.	Model	Play/Pause Button		
iOS	iPHONE	8.3	iPHONE 4 Series	Press once to Start or Stop audio	Press three times for Previous track	Press twice for Next track
		8.3	iPHONE 5 Series		Press three times for Previous track	Press twice for Next track
		8.3	iPHONE 6 Series	Press once to Start or Stop audio	Press three times for Previous track	Press twice for Next track
	iPAD	8.3	iPAD Series		Press three times for Previous track	Press twice for Next track
	IPOD	8.2	iPOD Series	Press once to Start or Stop audio	Press three times for Previous track	Press twice for Next track
	Note: This chart is for reference only. Operating functions need to be confirmed with your mobile phone's manufacturer.					