ARGENT M5 RGB

Optical Gaming Mouse User Guide

Table of Contents

Table of Contents

Table of Contents

Chapter 1:   TT iTAKE Installation

Step 1:

Launch the setup executable file (.EXE) file and click Next.

Step 2:

Click Install to begin the setup process.

Step 3:

Once setup is complete, you will also need to install the Microsoft Visual C++ 2015 Redistributable Package.

※ Without installing the Redistributable Package, the software will fail to launch.


Step 4:

Click Finish to complete the installation.

thermaltake

Chapter 2: Functions Available on the Home Page

Home Page

You can switch the mouse model.

Profiles

The Argent M5 RGB can support up to 6 profiles, which can be switched as required.

Configuration Pages

Switches between the configuration pages single-key operation, macro recording, lighting effects and performance setting.

Functions for Managing Profiles

Up to 15 profiles can be added for use. The functions of each button from left to right are:

Add: Create a new profile.
Delete: Delete an existing profile.
Copy: Copy a profile.
Import: Import a profile.
Export: Export a profile.

Correcting the Name of a Profile

The name of a new profile can be modified directly.

PC IP Address

Use the TT iTAKE APP to enter the IP for control.

Other Settings / Shrink Window / Close Window

Other Settings: Software version, Amazon Alexa setting and switching the language used for the user interface.
Shrink Window: Close the display and minimize the program to the taskbar.
Close Window: Close the display and minimize the program to the lower right corner.

MOUSE

PROFILE 1   PROFILE 2   PROFILE 3   PROFILE 4   PROFILE 5   PROFILE 6

CUSTOMIZE   MACROS   LIGHTING   PERFORMANCE

thermaltake

SELECT PROFILE
PROFILE 1

PROFILE NAME
PROFILE 1

1	LEFT CLICK
2	RIGHT CLICK
3	SCROLL CLICK
4	SCROLL UP
5	SCROLL DOWN

PROFILE	6
MOUSE BUTTON	7
MOUSE BUTTON	8
MOUSE BUTTON	9
MOUSE BUTTON	10

○ Left-handed   ◉ Right-handed

KEY ASSIGNMENT
Default

KEY RESET   APPLY

TT070010195, IP Address:192.168.4.176

Restore Mouse Settings for All Keys / Apply

Restore Mouse Settings for All Keys: All key functions saved under the current profile will be restored to factory default values.
**Apply:** Save and apply all settings to the selected key.

Assigning Key Functions

Eight different functions can be assigned.

thermaltake

Chapter 3:   Key Configurations

Step 1:

Select a key, then select a "Default" function from the drop-down list.


Step 2:

Click Apply to change and save the new function.

thermaltake

Step 1:

Select a key, then select "Single Key" from the drop-down list.

## Step 2:

Enter a new key value into the lower-right box.

thermaltake

Step 3:

Click Apply to change and save the new function.


Step 4:

Based on the information displayed on the screen, you will be able to see if the new key setting is applied properly.

Step 1:

First, you must designate a key, then select "Macro" in the drop-down list.

## Step 2:

Select a macro from the upper-right.

Step 3:

Select a macro repeat option from the drop-down list located in the lower-right corner.

Step 4:

Click Apply to save the new function. Verify if the new key function is applied properly by looking at the information displayed on the screen.

thermaltake

Step 1:
Select a key, then select "Media" from the drop-down list.

Step 2:
Select a multimedia function in the right drop-down list.

thermaltake

Step 3:
Click Apply to change and save the new function.

Step 4:
Based on the information displayed on the screen, you will be able to see if the new key setting is applied properly.

thermaltake

Step 1:

Select a key, then select "Function Keys" from the drop-down list.


Step 2:

Select a type of hotkey function in the upper-right drop-down list.

Step 3:

Select a keyboard function in the lower-right drop-down list.


Step 4:

Click Apply to save the new function. Verify if the new key function is applied properly by looking at the information displayed on the screen.

thermaltake

Step 1:

Select a key, then select "Launch Application" from the drop-down list.

Step 2:

Select "Application" in the upper-right drop-down list.

thermaltake

Step 3:

Click on the Open File button located on the bottom-right.

Step 4:

Select the executable file (.EXE) to open.

Step 5:
Click Apply to change and save the new function.

Step 6:
Based on the information displayed on the screen, you will be able to see if the new key setting is applied properly.

thermaltake

Step 1:

Select a key, then select "Launch Application" from the drop-down list.

Step 2:

Select "Web" in the upper-right drop-down list.

thermaltake

Step 3:
Enter the URL into the textbox located on the bottom-right and press Enter.

Step 4:
Click Apply to save the new function. Verify if the new key function is applied properly by looking at the information displayed on the screen.

Step 1:

Select a key, then select "Gaming Profile" from the drop-down list.

Step 2:

Select a game title in the upper-right drop-down list.

Step 3:

In the lower-right drop-down list, select an in-game action.


Step 4:

Click Apply to save the new function. Verify if the new key function is applied properly by looking at the information displayed on the screen.

Step 1:
Select a key, then select "Mouse" from the drop-down list.

Step 2:
Select a mouse function in the upper-right drop-down list.

thermaltake

Step 3:
Click Apply to change and save the new function.

Step 4:
Based on the information displayed on the screen, you will be able to see if the new key setting is applied properly.

Step 1:

Select a key, then select "Disable" from the drop-down list.

Step 2:

Click Apply to save the new function. Verify if the new key function is applied properly by looking at the information displayed on the screen.

thermaltake

Chapter 4: Functions Available on the Macro Page

New Macro / Delete / Copy / New Text / Import / Export

New macro: Create a new macro.
Delete: Delete a macro or text.
Copy: Copy a macro or text.
New text: Create a new text.
Import: Import a macro or text.
Export: Export a macro or text.

Modifying the Name of a Macro / Text

You can change the name of a new macro or text directly.

Macro Recording Settings

Record Delay Times: Record a macro based on the time interval between each keystroke.
Fixed Delay: Record a macro based on the specified time interval.
No Delay: Record a macro without recording the time interval between each keystroke.

Macro Recording Area

You can verify the sequence recorded by the macro and the key assignment.

Record / Delete / Insert / Pause / Edit

Record: Begin macro recording.
Delete: Delete the assigned value of a specific key.
Insert: Insert an additional value above or below the existing value of a specific key.
Stop: End macro recording.
**Edit:** Edit the delay time of a specific key.

# Chapter 5: How to Record Macros

Step 1:

Add a new macro and modify its name.

Step 2:

Select the delay method used to record the macro by using the checkboxes below.

Step 3:
Press the Record button.

Step 4:
Enter the sequence to be recorded from the keyboard, then press the Stop button to complete the recording.

Step 1:

Select a macro by clicking on the key it is assigned to.

Step 2:

Click the Insert button.

Step 3:

Select the position where new content is to be inserted.

Step 4:

Press the Record button.

Step 5:

Enter the sequence to be recorded from the keyboard.

Step 6:

Click the Stop button to complete the insertion process.

Step 1:

Add a new character set and modify its name.

Step 2:

Enter the values for the "Start Key" and "End Key" in the upper right corner.

thermaltake

Step 3:

Click on the input box located at the bottom-right corner and enter the characters to be recorded from the keyboard.

Step 4:

Click the Save button to complete the recording of the character set.

thermaltake

Chapter 5: Functions Available on the Lighting Effects Page

Lighting Effects

Mouse light of 9 lighting effects are supported: Static, Pulse, Blink, Wave, RGB Spectrum, Raindrops, Snake, Music Mode and System Temperature.

Lighting Effects Configurations

Can be used to adjust the color, direction, speed, and brightness level of the lighting effect within an area; can also be used to switch to random colors.

Apply / Restore Lighting Effect Settings

Apply: Apply the new lighting effect settings to all keys on the mouse.
Restore Lighting Effect Settings: All lighting effect settings saved under the current profile will be restored to factory default values.

Color Pattern Settings

Add Pattern: Add a new pattern with red to black gradient.
Delete Pattern: Delete the currently selected color pattern.
Insert Color Point: Add a red color point to the color pattern.
Delete Color Point: Delete the selected color point from the color pattern.

Color Wheel Settings

You can select a color from the color wheel directly or enter RGB color values to adjust the color of the lighting effect.

Chapter 6:   Lighting Effects Overview

Step 1:

Select "Static" in the Lighting Effect drop-down list.

Step 2:

Click on a color inside the color wheel or enter the RGB color values to change the color.

Step 3:

Adjust the brightness level of the mouse's backlight.

Step 4:

Click Apply to save the new settings.

Step 1:
Switch the zones to "Customized."

Step 2:
Click on a color inside the color wheel or enter the RGB color values to change the color.

Step 3:

Click on the mouse image directly with the left mouse button to change the key color.

※ Right click to cancel the color.

## Step 4:

Click Apply to save the new settings.

Step 1:
Select "Pulse" in the Lighting Effect drop-down list.

Step 2:
Click on a color inside the color wheel or enter the RGB color values to change the color.

## Step 3:

Adjust the backlight speed.

Step 4:

Click Apply to save the new settings.

Step 1:
Switch the zones to "Customized."

Step 2:
Click on a color inside the color wheel or enter the RGB color values to change the color.

Step 3:

Click on the mouse image directly with the left mouse button to change the

key color.

Step 4:

Click Apply to save the new settings.

Step 1:
Select "Blink" in the Lighting Effect drop-down list.

Step 2:
Click on a color inside the color wheel or enter the RGB color values to change the color.

Step 3:

Adjust the backlight speed.

Step 4:

Click Apply to save the new settings.

Step 1:
Switch the zones to "Customized."

Step 2:
Click on a color inside the color wheel or enter the RGB color values to change the color.

Step 3:

Click on the mouse image directly with the left mouse button to change the key color.

※ Right click to cancel the color.


Step 4:

Click Apply to save the new settings.

Step 1:

Select "Wave" in the Lighting Effect drop-down list.

Step 2:

Select a set of color patterns on the upper-right.

Step 3:

Set the direction, speed, and brightness level of the lighting effect.

Step 4:

Click Apply to save the new settings.

Step 1:
Add a new set of color patterns.

Step 2:
Add a new color-insertion point and drag it to the desired position.

Step 3:

Click on each color-insertion point to modify its color.

Step 4:

Click Apply to save the new settings.

Step 1:

Select "RGB Spectrum" in the Lighting Effect drop-down list.

Step 2:

Set the speed and brightness level of the backlight and click on Apply

to save the new settings.

Step 1:
Select "Raindrops" in the Lighting Effect drop-down list.

Step 2:
Click on a color inside the color wheel or enter the RGB color values to change the color.

thermaltake

Step 3:

Set the speed and brightness level of the backlight.

Step 4:

Click Apply to save the new settings.

Step 1:
Select "Snake" in the Lighting Effect drop-down list.

Step 2:
Click on a color inside the color wheel or enter the RGB color values to change the color.

Step 3:

Set the direction, speed, and brightness level of the lighting effect.

Step 4:

Click Apply to save the new settings.

Step 1:

Select "Music Mode" in the Lighting Effect drop-down list.

Step 2:

Set the desired mode of lighting effects.

Step 3:

Click on a color inside the color wheel or enter the RGB color values to change the color of each row.


Step 4:

Click Apply to save the new settings.

Step 1:
Select "Temperature" in the Lighting Effect drop-down list.

Step 2:
Click Apply to save the new settings.

Chapter 7: Functions Available on the Performance Page

Sensitivity Stage

A sensitivity stage is a preset sensitivity value. You can switch up to 6 different sensitivity stages which you can cycle through using the DPI cycle button.

Enable X-Y Sensitivity: By default, the X-axis(horizontal) and Y-axis(vertical) use the same sensitivity values. However, you may set different sensitivity values to each of the axes by the Enable X-Y Sensitivity option.

Polling Rate

The higher the polling rate, the more often the computer receives information about the status of your mouse, thus increasing the mouse pointer's reaction time.

Button Response

The lower the response, the more often the computer receives information about the status of your mouse, thus increasing the mouse button reaction time.

Angle Snapping

Angle Snapping corrects minor imperfections when you try to move your mouse in straight horizontal or vertical paths. This can increase precision if you are simultaneously turning and shooting in a first person shooter or drawing lines in a graphics editing application.

Chapter 8: Functions Available on the Settings Page

Language Settings

Sets the language of the program's user Interface and theme.

Razer Chroma On / OFF

Users who have installed both the TT iTAKE Software and Razer Synapse 3 can experience synchronized gaming and RGB lighting effects on their gaming gear.

Amazon Alexa Login

TT iTAKE software support Amazon Alexa voice service, allowing you to control the lights by talking to the Alexa Enabled device.

TT iTAKE APP Password Setting

Enter four number or English alphabet.

※ Empty is disable function.

Official Website / Social Media

Official Website: Visit the Product official website.
Social Media: Visit Thermaltake on Facebook.

MOUSE

LANGUAGES
English

THEME
Default

WORKS WITH
RAZER CHROMA
RGB

OFF (beta)

amazon alexa (beta)
ACCOUNT
PASSWORD
LOGIN
ian Up

MOBILE APP PASSWORD
OFF

OFFICIAL WEBSITE / SOCIAL MEDIA
thermaltake   facebook

SOFTWARE VERSION :   v1.4.6

TT070010195, IP Address:192.168.4.176

Software Version

Software Version: Displays the version number of the installed program.

Chapter 8: TT iTAKE App Features Overview

Step 1

Open the App Store.

Step 2

Enter "TT iTAKE" into the search bar.

Step 3

Tap to download.

Step 1

Launch the TT iTAKE app.

Step 2

Open the TT iTAKE Engine Software and set your TT iTAKE App password.

Step 3

Click to scan for devices.

Step 4

In order to establish a connection, click on the IP address of the computer you wish to connect to.

※If the IP address is not found, please try again to scan for your device.
In addition, please verify that the keyboard software is activated. If your device still cannot be found, please use the manual connection method (described on the next page).

Step 5

Enter TT iTAKE App password.

Connection Guide

※ Before attempting to establish a connection, please read these instructions carefully to prevent problems when searching for your device.

Step 1

Enter the computer's IP address.

Step 2

Click on the "Connect" button.

Pulse

No SIM 📶   10:50 AM   100% 🔋
≡ LIGHTING   ⌄   L20 GT

RANDOM

BRIGHTNESS
0

SPEED
4

💡 LIGHTING   Pulse >
🖌 PATTERN / MODE   Off >

Switching Device
TT iTAKE Engine software support devices.

Step 3
Select the color you wish to adjust or switch to random color mode (once activated, color selection is no longer available).

Step 4
Set the desired speed to complete the settings.

Step 1
Click this area.

Pulse

No SIM 📶   10:50 AM   100% 🔋
≡ LIGHTING   ⌄   L20 GT

RANDOM

CANCEL   OK
LIGHTING   PATTERN / MODE

Static
Pulse   Off
Blink
Wave
Spiral Rainbow

Step 2
Select the lighting effects.

thermaltake

Wave

Wave

Switching Devices

TT iTAKE Engine software support devices.

Step 3

Select the direction of running lights.

Step 4

Set the desired speed and brightness level to complete the settings.

Step 1

Click this area.

Step 2

Select the lighting effects and preconfigured color patterns available in the program (the number indicates the order).

Step 1

Click to select the menu in the upper-left corner.

Step 2

Select "Macro".

Step 3

Select the key position for adding a new macro.

Step 4

Select a previously recorded macro from the program.

Step 5

Select the type of game the macro will be used for.

Step 6

Tap OK to complete the settings.

Step 7

Tap on the button to activate the macro.

Step 1

Tap the icon located in the upper-right corner to enter editing mode.

Step 2

Tap the trash can icon to delete the macro.

Step 3

Tap the confirmation icon located in the upper-right corner to exit editing mode.

Step 1

Click to select the menu in the upper-left corner.

Step 2

Select "Voice Control".

Step 3

After tapping on the microphone icon, the app will begin to listen for voice commands.

※Please refer to the next page for a list of voice commands.

You can say...

Wave
Indigo Color
Extreme
Slow
Turn off

thermaltake

Note	Command (Chinese)	Command (English)	Description
Color mode	紅色	Red Color	Change all LED color "Red"
	橙色	Orange Color	Change all LED color "Orange"
	黃色	Yellow Color	Change all LED color "Yellow"
	綠色	Green Color	Change all LED color "Green"
	藍色	Blue Color	Change all LED color "Blue"
	靛色	Indigo Color	Change all LED color "Indigo"
	紫色	Purple Color	Change all LED color "Purple"
	白色	White Color	Change all LED color "White"
	彩色	Rainbow	Default color
Light mode	全亮	Static	Full Lighted mode
	呼吸	Pulse	Pulse mode
	波浪	Wave	Wave mode
	旋轉	Spiral	Spiral Rainbow Wave mode
	流動	Flow	Flow mode, could not change color
	循環	Spectrum Cycling	RGB Spectrum mode, could not change color
	雨滴	Raindrops	Raindrops mode
	跑馬燈	Snake Marquee	Snake Marquee mode
	反應	Reactive	Reactive mode
	閃爍	Blink	Blink mode
	哈囉 TT	Hello TT	Special mode

thermaltake

Note	Command (Chinese)	Command (English)	Description
Light Speed	速度極快	Extreme	Light speed "Extreme"
	速度快	Fast	Light speed "Fast"
	速度慢	Normal	Light speed "Normal"
	速度極慢	Slow	Light speed "Slow"
	快一點	Quickly	Change the light speed quickly
	慢一點	Slowly	Change the light speed slowly
Switch	關燈	Turn Off	Turn off all LED light
	開燈	Turn On	Turn on all LED light
	結束	End	Leave voice input
Brightness	燈光最亮	Glaring	Brightness 100%
	燈光亮	Bright	Brightness 75%
	燈光暗	Dim	Brightness 50%
	燈光最暗	Dark	Brightness 25%

thermaltake

Basic Command			Color command
Wake up Alexa	**Command**	**Light Mode**	**Color**
Alexa tell / ask / open Thermaltake	Use / Switch / Change	Static Mode Pulse Mode RGB Spectrum Mode Raindrop Mode Blink Mode	in Red color
			in Orange color
			in Yellow color
			in Green color
			in Blue color
			in Indigo color
			in Purple color
			in White color
			in Rainbow color
		Wave Mode Temperature Mode Hello TT Mode	Preset modes with no color options.

thermaltake